

Gold

IR TOUCH PAD CONTROLLER

MODEL G41-W



FUNCTION

The IR Touch Pad Controller provides wall access and immediate adjustments for the System. The Touch Pad option is often chosen for spaces such as conference rooms and board rooms, or any area where individualized and on-going adjustments are desired.

Located on the wall plate used for the Touch Pad is an LED light indicator that identifies the current function of the system that is being adjusted. The system functions that can be adjusted are masking, paging, music, test and IR/ALL.

To use the Touch Pad use the left and right arrow keys in the center of the pad to select the function types (masking, paging, music, test, IR/ALL) that you wish to adjust. Once the system function is selected, use the up and down arrows to increase or decrease the volume. To mute and un-mute the system, simply press the Mute/Un-mutes button located at the bottom of the wall plate. The IR/All function enables end users to mute or unmute the masking, paging and music all at the same time.

WALLPLATE

+ Dimensions – 2 ¾" w x 4 ¼" h

WIRE REQUIREMENTS

+ Cat 5e cable or equivalent 4 Twisted pair
+ Standard RJ45 connector

INSTALLATION

To connect to the System's OP, use a patch cable using Cat 5E with RJ45 connectors and connect the wire from the OP's IR Port to the back of the wall plate. If an IR Hub has been specified for multiple controls, the patch cable can be run from the OP to an IR Hub and then to each channel of the IR Hub (A, B, C, D).