



USER MANUAL

IR HUB
G964

Rev B

IR Hub User Manual

Each OP, Silver, and A1U unit is equipped with an IR port on the enclosure. This port allows an IR keypad or wallplate to control the unit's speaker channels' volume for masking, music, and paging.

The IR Hub is an additional component that allows for more than one keypad or wallplate to be installed in an IR port allowing individual channel volume adjustments for masking, music and paging. Up to four keypads or wallplates may be installed in each hub allowing each channel to be adjusted by an individual keypad or wallplate.



Spectra i.Net IR Hub



* IR Eye
(sold separately)



* IR keypad
(sold separately)

Note: See separate manuals for the IR eye, IR keypad, and IR remote control.

IR Hub User Manual

IR HUB – CONNECTING TO MORE THAN ONE IR eye or IR keypad.

When installing more than one IR eye or IR keypad to a unit, use the IR Hub as shown below. In this configuration, each IR eye controls a separate speaker channel. The IR Hub has 4 ports labeled "A", "B", "C", and "D." The IR eye or keypad will control the channel it is plugged into on the IR Hub. The IR Hub is powered by a 120VAC wall adapter (included).



IR eye or IR Keypad
Each IR eye controls a separate speaker channel