

# APPLICATION

# NOTE: 3

System Manager 2  
Third Party Interface  
RESTful IP Communication

# APPLICATION NOTE

## System Manager 2 Third Party Interface RESTful IP Communication

### Contents

Third Party Interface.....	1
TCP/IP.....	1
TPI Protocol .....	1
Protocol Definition .....	1
RESTfulcommunication: .....	1
Example using Postman .....	5
i.NET® OP Communication Messages .....	10
System Manager (dB) to TPI Comparison Chart .....	16

# APPLICATION NOTE

## System Manager 2 Third Party Interface RESTful IP Communication

### Third Party Interface

While the iLON SmartServer based System Manager 2 came with a third-party interface (TPI) based on Sockets and TCP/IP, the Processor based version of System Manager 2 comes with a RESTful interface to allow more sophisticated access to the system.

### TCP/IP

In order to connect to System Manager 2 and the Processor for purposes of third-party control via TCP/IP, you must establish a connection to the REST endpoint using a TCP/IP client to the IP address of the Processor using port 80. Once connected, you can control the Lencore hardware using the protocol that is listed later in the document.

### TPI Protocol

The TPI supports a wide range of control and queries, where one can control an i.Net<sup>®</sup> OP directly. It should be noted, that the TPI will NOT return a response, with data, when sending Zone control, as the messages for Zone control are one way. However, with direct control of the OP, you will receive responses, with data, from query message requests. However, you will always get confirmation REST responses for all commands.

When sending direct OP messages, you should wait for a reply until you send the next message. With Zone control messages, since you won't get a response, you should wait 500ms between messages. This document will not list all commands available, only the common commands that a TPI control system may use.

### Protocol Definition

- All protocol values are listed in actual decimal values and should not be mistaken for ASCII encoded values.
- An OP message is a collection of parameters where each parameter is represented as a byte.
- The message is composed of 6 parameter bytes and up to 25 data bytes.
- See page 12 for examples of message string sequences.
- In this document, all parameters are shown as decimal numbers not hexadecimal numbers.

### RESTful communication:

A typical REST call looks like the following:

```
// typical rest JSON request fields
parameters (object)
```

```
// example
{
    "parameters": { }
```

# APPLICATION NOTE

## System Manager 2 Third Party Interface RESTful IP Communication

A typical RESTful response would look like this:

```
// typical rest JSON response payload fields
```

```
message (string)
```

```
data (object)
```

```
error (string)
```

```
// response
```

```
{  
    "message": "",  
    "data": { },  
    "error": ""  
}
```

Before any meaningful control can be done with the TPI interface, you must first login to the Processor and get a "token", as follows:

Resource endpoint//

<http://ip.address/rest/login>

```
// login parameters: username and password
```

*Default username and password are "comfort"*

```
// example ("HTTP GET" Request)
```

**<http://<ip.address>/rest/login?username=somename&password=somepassword>**

```
// example normal login response payload
```

```
{  
    "message": "Logged in ok",  
    "data": {  
        "token": "eyJ0eXAiOiJKV1QiLCJhbGciOiJIUzI1NiJ"  
    },  
    "error": null  
}
```

# APPLICATION NOTE

## System Manager 2 Third Party Interface RESTful IP Communication

Now that we have a basic connection established, we can control various functions. A typical API call to control the volume of Masking Attenuation would look like this:

Example Payload of a request to a single OP:

```
// "OP" example request payload (MASK_ATTENUATION (set channel A volume))
```

```
{
  "parameters": { "OPAddress": 1, "OPGroupSelect": 0, "OPCommandCat": 1, "OPSubCommand": 1,
  "OPTtransactionID": 88, "OPDataCount": 7, "OPData": [49] }
}
```

```
// "OP" example response payload (MASK_ATTENUATION (set channel A volume))
```

```
{
  "message": "Call successful",
  "data": {
    "OPAddress": 1,
    "OPResultCode": 1,
    "OPCommandCat": 1,
    "OPSubCommand": 1,
    "OPTtransactionID": 244,
    "OPDataCount": 7,
    "OPData": [
      49,
    ]
  },
  "error" : null
}
```

# APPLICATION NOTE

## System Manager 2 Third Party Interface RESTful IP Communication

The specific API call is implemented as below. Refer to the command listings at the end of this document for all the parameters.

// Control Resource endpoint

*http://ip.address/rest/method/TPI/control*

// control parameters

happn\_token // Auth Token parameter- This is the Token from above login process

// control "parameters" JSON request payload

OPAddress (unsigned byte)

OPGroupSelect (unsigned byte)

OPCommandCat (unsigned byte)

OPSubCommand (unsigned byte)

OPTtransactionID (unsigned byte) (Transaction ID is ignored)

OPDataCount (unsigned byte)

OPData (unsigned byte array)

// control "data" JSON response payload

OPAddress (unsigned byte)

OPResultCode (unsigned byte)

OPCommandCat (unsigned byte)

OPSubCommand (unsigned byte)

OPTtransactionID (unsigned byte) (Transaction ID is actual used)

OPDataCount (unsigned byte)

OPData (unsigned byte array)

// example ("HTTP POST" Request)

**http://<ip.address>/rest/method/TPI/control?happn\_token=eyJ0eXAiOiJKV1QiLCJhbGciOiJIUzI1**

// "OP" example payload (set MASK\_ATTENUATION (chA))

```
{
  "parameters": { "OPAddress": 1, "OPGroupSelect": 0, "OPCommandCat": 1,
  "OPSubCommand": 1, "OPTtransactionID": 0, "OPDataCount": 7, "OPData": [49] }
}
```

# APPLICATION NOTE

## System Manager 2 Third Party Interface RESTful IP Communication

### Example using Postman

GET token:

<http://192.168.100.253/rest/login?username=comfort&password=comfort>

The screenshot shows the Postman interface for an API test. The URL is `http://192.168.100.253/rest/login?username=comfort&password=comfort`. The request method is GET. The response status is 200 OK, with a time of 315 ms and a size of 597 B. The response body is displayed in JSON format, showing a successful login with a message, data, token, and error field.

API test / <http://192.168.100.253/rest/login?username=comfort&password=comfort>

GET `http://192.168.100.253/rest/login?username=comfort&password=comfort` **Send**

Params Authorization Headers (6) Body Pre-request Script Tests Settings Cookies

Query Params

	KEY	VALUE	DESCRIPTION	...	Bulk Edit
<input checked="" type="checkbox"/>	username	comfort			
<input checked="" type="checkbox"/>	password	comfort			
	Key	Value	Description		

Body Cookies Headers (4) Test Results Status: 200 OK Time: 315 ms Size: 597 B Save Response

Pretty Raw Preview Visualize JSON 🔍

```
1  {
2    "message": "Logged in ok",
3    "data": {
4      "token": "eyJ0eXAiOiJKV1QiLCJhbGciOiJIUzI1NiJ9.
           Im1lkfGRmNmY2MmY4LTA3NDAtNGFjMi1iOGYwLTJmOTdlZGNmODgxYnx0eXB1fHRpbWVzdGFtcHxwb2xpY3I8MHx0dGx8aw5hY3Rpdml0eV90aHJlc2hvbGR8MXxwZXJtaXNzaW9uU2V0S2V5fC9ftUVTSF9BRE0vL19NRVNIX0dTVC8vX1NMi98aXNub2t1bnx1c2VybWZxXjB21mb3J0XjB8TDQ3QjJZVzZ8MHwwX14kMHwxZD8J8RXwzfEZ8NHwkNXwkNnxHfDd8LTNdFdh8JDZ8SHw3fC0zXV18OXxBfEJ8LTF8Q3xEXSI.9Yco0P2eQbsFM0p1Zq2jxNOD6EavhS0oMkhcUUGAJjk"
5    },
6    "error": null
7  }
```

# APPLICATION NOTE

## System Manager 2 Third Party Interface RESTful IP Communication

POST masking volume change to channel A:

http://192.168.100.253/rest/method/TPI/control?happn\_token= eyJ0eXAiOiJKV1QiLCJhbGciOiJIUzI1NiJ

Parameters:

Params ☒ Authorization Headers (9) Body ☒ Pre-request Script Tests Settings

Query Params

	KEY	VALUE	
<input checked="" type="checkbox"/>	happn_token	eyJ0eXAiOiJKV1QiLCJhbGciOiJIUzI1NiJ9.eyJmImkGFRmNm...	
	Key	Value	

Headers:

Params ☒ Authorization Headers (9) Body ☒ Pre-request Script Tests Settings

Headers ☐ 8 hidden

	KEY	VALUE	
<input checked="" type="checkbox"/>	Content-Type	application/json	
	Key	Value	

Body:

Params ☒ Authorization Headers (9) Body ☒ Pre-request Script Tests Settings

☐ none ☐ form-data ☐ x-www-form-urlencoded ☒ raw ☐ binary ☐ GraphQL JSON

```
1 {
2   "parameters": { "OPAddress": 1, "OPGroupSelect": 0, "OPCommandCat": 1,
3   "OPSubCommand": 1, "OPTtransactionID": 88, "OPDataCount": 7, "OPData": [49] }
4 }
```



# APPLICATION NOTE

## System Manager 2 Third Party Interface RESTful IP Communication

API test / http://192.168.100.253/rest/login?username=comfort&password=comfort

Save

...



POST

http://192.168.100.253/rest/method/TPI/control?happn\_token=eyJ0eXAiOiJKV1QiLCJhbGciOiJIUzI1NiJ9.eyJmImkfcGRmNmY2MmY4LTA3NDAtNGF...

Send

Params Authorization Headers (9) Body Pre-request Script Tests Settings

Cookies

none form-data x-www-form-urlencoded raw binary GraphQL JSON

Beautify

```
1 {
2   "parameters": { "OPAddress": 1, "OPGroupSelect": 0, "OPCommandCat": 1,
3   "OPSubCommand": 1, "OPTtransactionID": 88, "OPDataCount": 7, "OPData": [49] }
4 }
```

Body Cookies Headers (4) Test Results

Status: 200 OK Time: 415 ms Size: 310 B

Save Response

Pretty

Raw

Preview

Visualize

JSON



```
1 {
2   "message": "Call successful",
3   "data": {
4     "OPAddress": 1,
5     "OPResultCode": 1,
6     "OPCommandCat": 1,
7     "OPSubCommand": 1,
8     "OPTtransactionID": 244,
9     "OPDataCount": 7,
10    "OPData": [
11      49
12    ]
13  },
14   "error": null
15 }
```

# APPLICATION NOTE

## System Manager 2 Third Party Interface RESTful IP Communication

*Example of a change to all OP's:*

// GLOBAL example payload (set MASK\_ATTENUATION (chA))

```
{
  "parameters": { "OPAddress": 0, "OPGroupSelect": 127, "OPCommandCat": 1,
    "OPSubCommand": 1, "OPTTransactionID": 88, "OPDataCount": 7, "OPData": [49] }
}
```

// example GLOBAL response payload example (set MASK\_ATTENUATION (chA))

```
{
  "message": "Call successful",
  "data": "Success",
  "error": null
}
```

*Example of a change to a group of OPs by using a masking Zone:*

// "MASK ZONE 1" example response payload example (set MASK\_ATTENUATION (chA))

```
{
  "parameters": { "OPAddress": 1, "OPGroupSelect": 1, "OPCommandCat": 1,
    "OPSubCommand": 1, "OPTTransactionID": 88, "OPDataCount": 7, "OPData": [49] }
}
```

// "MASK ZONE 1" example response payload example (set MASK\_ATTENUATION (chA))

```
{
  "message": "Call successful",
  "data": "Success",
  "error": null
}
```

# APPLICATION NOTE

## System Manager 2 Third Party Interface RESTful IP Communication

```
// "OP" example response payload example (set MASK_ATTENUATION (chA))
{
  "message": "Call successful",
  "data": {
    "OPAddress": 1,
    "OPResultCode": 1,
    "OPCommandCat": 1,
    "OPSubCommand": 1,
    "OPTransactionID": 19,
    "OPDataCount": 7,
    "OPData": [
      49
    ]
  },
  "error": null
}

"data": "Success", "error":
null
}
```

In all the above examples, all the parameters come from the list of commands on page 10. Each command is 31 bytes.

# APPLICATION NOTE

## System Manager 2 Third Party Interface RESTful IP Communication

### i.NET® OP Communication Messages

#### OP\_Request Header.

##### Request header

Byte 1 = OP Address	= 1 to 199	if parameter 2 is INDIVIDUAL.
= Group number	= 1 to 255	if parameter 2 is MASK_GROUP, PAGE_GROUP or MUSIC_GROUP.
= Global	= 0	if parameter 2 is GLOBAL_SELECT.
Byte 2 = Group Select	= 0	INDIVIDUAL
	= 1	MASK_GROUP
	= 10	PAGE_GROUP
	= 20	MUSIC_GROUP
	= 127	GLOBAL_SELECT
Byte 3 = Command Category	= 1	MASK_ATTENUATION
	= 10	PAGE_ATTENUATION
	= 20	MUSIC_ATTENUATION
Byte 4 = Sub Command	= 1	Set value for channel A
(dependent on	= 2	Set value for channel B
command category)	= 3	Set value for channel C
	= 4	Set value for channel D
	= 5	Set value for all four channels
	= 6	Request current value for channel A
	= 7	Request current value for channel B
	= 8	Request current value for channel C
	= 9	Request current value for channel D
	= 10	Request current value for all four channels
	= 11 to 21	Dependent on command category
Byte 5 = Transaction ID	= 1 to 255	
Byte 6 = Parameter count	= 6 + any data bytes	
Bytes 7 to 31	= 25 available data bytes	

#### OP\_Response Header.

##### Response header

Byte 1 = OP Address	= 1 to 199 or ...	
= Group number	= 1 to 255 or ...	
= Global	= 0	
Byte 2 = Result Code	= 1	COMMAND_SUCCESS
	= 2	COMMAND_FAIL
	= 3	NO_RESPONSE_FROM_DSP
Byte 3 = Command Category	= 1	MASK_ATTENUATION
	= 10	PAGE_ATTENUATION
	= 20	MUSIC_ATTENUATION
Byte 4 = Sub Command	= 1 to 21	Dependent on command category
Byte 5 = Transaction ID	= 1 to 255	
Byte 6 = Byte count	= 6 to 31	
Bytes 7 to 31	= Return data bytes if any	

## System Manager 2 Third Party Interface RESTful IP Communication

Note: Assume OP-1, all sample values set to **DEFAULT**, and Transaction ID set to 88.

chart at the end of this document.

[illegible][illegible]

! The Req.'s (request for current values), can only use **INDIVIDUAL** or **GLOBAL\_SELECT**.

[illegible][illegible]

! The Req.'s (request for current values), can only use **INDIVIDUAL** or **GLOBAL\_SELECT**.

## System Manager 2 Third Party Interface RESTful IP Communication

[illegible][illegible]

12

## System Manager 2 Third Party Interface RESTful IP Communication

Note: Unused data bytes should not be sent. For example, if the byte count is 7, only 7 bytes should be sent. Trailing zeros should not be sent. See dB to TPI comparison chart at the end of this document.

**Example 4** sets music group 2 attenuation to 48 dB (28).  
Example command = "2 20\_20 20 91 7 **28**"

Example response from **example 4** above.  
Response\_Msg = "2 1 20 20 91 7 28 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0"

The "88" is the transaction ID. It can be any number between 1 and 255

# APPLICATION NOTE

## System Manager 2 Third Party Interface RESTful IP Communication

### List of required "Response" parameter count

#### MASK\_ATTENUATION

SubCommand 1 to 9, Required byte count = 1 + header = 7

SubCommand 10, Required byte count = 6 + header = 12  
See below for byte 11, 12 decoding.

#### PAGE\_ATTENUATION

SubCommand 1 to 9, Required byte count = 1 + header = 7

SubCommand 10, Required byte count = 6 + header = 12  
See below for byte 11, 12 decoding.

#### MUSIC\_ATTENUATION

SubCommand 1 to 9, Required byte count = 1 + header = 7

SubCommand 10, Required byte count = 6 + header = 12  
See below for byte 11, 12 decoding.



# APPLICATION NOTE


## System Manager 2 Third Party Interface RESTful IP Communication

### Superflag byte 11 (MSB) and 12 (LSB) decoding:

From returned bytes in Req ch **all MASK\_ATTENUATION** sub command 10  
Or  
From returned bytes in Req ch **all PAGE\_ATTENUATION** sub command 10  
Or  
From returned bytes in Req ch **all MUSIC\_ATTENUATION** sub command 10

A 0 in bit position means the channel is unmuted. (Default)  
A 1 in bit position means the channel is muted.

Bit position:



# APPLICATION NOTE

## System Manager 2 Third Party Interface RESTful IP Communication

### System Manager (dB) to TPI Comparison Chart

<b><u>System Manager (dB) Value</u></b> <b>to TPI Value Comparison</b>	
Mask Attenuation:	
<b><u>System Manager</u></b> <b><u>(dB) Value</u></b>	<b><u>TPI Value</u></b>
82.5	97
82	96
81.5	95
81	94
80.5	93
80	92
79.5	91
79	90
78.5	89
78	88
77.5	87
77	86
76.5	85
76	84
75.5	83
75	82
74.5	81
74	80
73.5	79
73	78
72.5	77
72	76
71.5	75
71	74
70.5	73
70	72
69.5	71
69	70
68.5	69
68	68
67.5	67
67	66
66.5	65
66	64
65.5	63
65	62

# APPLICATION NOTE

## System Manager 2 Third Party Interface RESTful IP Communication

64.5	61
64	60
63.5	59
63	58
62.5	57
62	56
61.5	55
61	54
60.5	53
60	52
59.5	51
59	50
58.5	49 (Default)
58	48
57.5	47
57	46
56.5	45
56	44
55.5	43
55	42
54.5	41
54	40
53.5	39
53	38
52.5	37
52	36
51.5	35
51	34
50.5	33
50	32
49.5	31
49	30
48.5	29
48	28
47.5	27
47	26
46.5	25
46	24
45.5	23
45	22
44.5	21
44	20

# APPLICATION NOTE

## System Manager 2 Third Party Interface RESTful IP Communication

43.5	19
43	18
42.5	17
42	16
41.5	15
41	14
40.5	13
40	12
39.5	11
39	10
38.5	9
38	8
37.5	7
37	6
36.5	5
36	4
35.5	3
35	2
34.5	1
34	0 (off)

Page / Music Attenuation:	
<b><u>dB Value</u></b>	<b><u>TPI Value</u></b>
82.5	49
81.5	48
80.5	47
79.5	46
78.5	45
77.5	44
76.5	43 (Default)
75.5	42
74.5	41
73.5	40
72.5	39
71.5	38
70.5	37
69.5	36
68.5	35
67.5	34
66.5	33

# APPLICATION NOTE

## System Manager 2 Third Party Interface RESTful IP Communication

65.5	32
64.5	31
63.5	30
62.5	29
61.5	28
60.5	27
59.5	26
58.5	25
57.5	24
56.5	23
55.5	22
54.5	21
53.5	20
52.5	19
51.5	18
50.5	17
49.5	16
48.5	15
47.5	14
46.5	13
45.5	12
44.5	11
43.5	10
42.5	9
41.5	8
40.5	7
39.5	6
38.5	5
37.5	4
36.5	3
35.5	2
34.5	1
34	0 (off)

Lencore Acoustics LLC  
835 New York Ave. Suite 21  
Huntington, NY 11743  
516-682-9292  
[info@lencore.com](mailto:info@lencore.com)  
[www.lencore.com](http://www.lencore.com)